

ISOMETER® isoCHA425HV


with AGH420-1/AGH421-1



ISOMETER® isoCHA425HV with AGH420-1/AGH421-1

The ISOMETER® isoCHA425HV in combination with the AGH420-1/AGH421-1 coupling device monitors the insulation resistance for DC fast charging stations according to the CHAdeMO standard or according to the Combined Charging System (CCS) for nominal system voltage ranges between DC 0 V and 1000 V.

- Switchable between CCS (Combined Charging System) and CHAdeMO
- Nominal voltages up to DC 1000 V
- Detection of symmetrical and asymmetrical insulation faults
- Electrically isolated Modbus RTU interface
- Display of the fault location (DC-balanced)





- Only one device for use in all regions and applications
- Compact design for optimum utilisation of the available installation space
- High system reliability and availability of the charging station thanks to patented measuring method
- Cost-optimised installation thanks to reduced wiring effort and a wide range of communication interfaces



Standards

A high level of electrical safety is a priority for DC charging stations. In order to minimise the risk to the user, the ISOMETER® isoCHA425HV fulfils all the important requirements placed on the insulation monitoring device by the standards and regulations.

- IEC 61851-23:2023 ED2
- UL 2231-1 / -2
- EN 61557-8
- CCS1 (US) / CCS2 (Eur)
- CHAdeMO













CCS1




CCS₂



Patented and reliable measuring methods ensure a high degree of safety and high availability of the DC charging station

- Detection of insulation faults up to $2 M\Omega$
- Maximum allowed system leakage capacitance of 20 μF – Unique in the market
- Active measuring method can detect symmetrical and asymmetrical insulation faults
- Voltage measurement with overvoltage and undervoltage detection
- Automatic device self-test with connection monitoring

- High system reliability
- High availability of the charging station
- Ideal for e-bus charging applications etc. thanks to high permissible leakage capacitance




Form factor and connections

The demand for elegant and compact fast charging stations is on the rise.
The ISOMETER® isoCHA425HV supports this trend with its compact design.

- Most compact design in the market:
 - Coupling device AGH420-1/AGH421-1: 36 mm x 93 mm (W x H)
 - ISOMETER® isoCHA425HV 36 mm x 93 mm (W x H)
- Flexible arrangement of insulation monitoring and coupling device
- Push-In wire connectors

Benefits:

- Optimum utilisation of the available installation space within the charging station
- Time savings during production thanks to fast wiring






Interfaces and communication

- RS-485
- Modbus RTU
- IsoData
- LC display
- Password protection against unauthorised parameter changes

- Quick and easy integration of the IMD in the charge controller using standard protocols
- Simple troubleshooting on site by means of the LC display









Coupling device AGH421-1

In fast charging stations with dynamic load distribution to two charging points, one IMD often has to be disconnected from the grid to avoid interference as long as the maximum power of a charging station is only made available to one vehicle.


The new AGH421-1 coupling device in combination with the ISOMETER® isoCHA425HV enables disconnection from the grid without the installation of additional switching units.

- Cost and space savings within the charging station by eliminating additional switching units
- Reduced wiring effort during the production process





IMD 2 disconnected from the system to be monitored



The entire available power is used for charging one vehicle. IMD2 must be disconnected to avoid interference



Bender GmbH & Co. KG

Londorfer Straße 65 35305 Grünberg Germany

Tel.: +49 6401 807-707 emobility@bender.de www.bender.de/en

Fotos: Adobe Stock (© Southworks, © BornHappy) and Bender Archive.

2248en / 05.2024 / © Bender GmbH & Co. KG, Germany – subject to change! The specified standards take into account the version valid at the time of printing.



